

Cutlerease® 6 EASY STEPS TO CLEAR A JAM

STEP 1



Start by sliding the tower partially or fully out of base (do NOT place on side or tip upside down, keep the tower upright).

STEP 2



Open bottom slide track.

STEP 3



Clear any cutlery inside.

STEP 4



Snap slide track back into position. You will hear an AUDIBLE SNAP once its securely in place.

STEP 5



Prime **ONLY ONCE** using the trigger. (priming more than once can make it jam again).

STEP 👩



Fully slide back the tower into the base.





Scan this QR code to watch our online troubleshooting video for more details.







